Cord sew instruction:

Step:

• 1. Cave the needed space for cord lock on the fabric



• 2. Leave the option part outside the hole



• 3. Sew the cord lock through sew-tab on the fabric



*Use #14 Needle, needle space 2.3~2.5mm